


An Implementation of Single-View Metrology

Presentation by Shih-Yu Sun

May 11, 2011

6.869 Final Project

Single-view metrology extracts 3D geometric information from a single image




- **Planar homography** gives the positions of the elements
- Heights could be estimated using **vanishing points/lines**

A. Criminisi, I. Reid, and A. Zisserman, "Single view metrology,"
International Journal of Computer Vision, vol. 40, 2000, p. 123–148.

Planar homography can be determined by four correspondences


- $[X \ Y \ 1]^T = H [x \ y \ 1]^T$
 - X, Y : world-frame coordinates on the plane
 - x, y : image plane coordinates



Distance from the reference plane could be computed based on vanishing points

$$\alpha R = - \frac{\|b \times t\|}{(l \cdot b) \|v_z \times t\|}$$


$$H = - \frac{\|b_0 \times t_0\|}{\alpha(l \cdot b_0) \|v_z \times t_0\|}$$





Distance from the reference plane could be computed based on vanishing points

$$\alpha R = -\frac{\|b \times t\|}{(l \cdot b)\|v_z \times t\|}$$

$$H = -\frac{\|b_0 \times t_0\|}{\alpha(l \cdot b_0)\|v_z \times t_0\|}$$




Complete 3D reconstruction of the MIT COOP was performed




unit: cm

Complete 3D reconstruction of the MIT COOP was performed




unit: cm

Complete 3D reconstruction of the MIT COOP was performed



unit: cm

Complete 3D reconstruction of the MIT COOP was performed



unit: cm

An application of 3D reconstruction in MIT 150 FAST Light

