

# Laboratory Course n° 4

—

## Compact Vision System

---

### *Objective*

Study and program a Compact Vision System from KEYENCE

### *Equipment*

- Controller unit (CV-2100)
- Remote control console (OP-42342)
- Monitor cable (RCA - RCA, 2 m)
- Camera (CV-020)
- CV-C3: Camera cable (3 m)
- Monitor CA-MN80
- 24 V DC power supply
- Industrial Parts & Backlight

### *Software*

- Embedded KEYENCE Software

### *Documentation*

- User Manual - High-speed Digital Image Sensor CV-2100


# Laboratory Course n° 4

---

## Compact Vision System

### Installation

In order to carry out this step, consult the user manual



1. Connect Cables
2. Start Grabbing images

Study user manual chapter 3 for Basic Operation.

Set Camera Settings (chapter 4.2) to obtain a satisfactory image of the shadow of the part.

# Laboratory Course n° 4


—

## Compact Vision System


---

### Edge Detection

You have to program edge detection in order to characterize the holder width on the industrial part.



By using "Edge Pitch" Measurement Mode program the following measure to estimate the width of the holders:



Follow carefully the steps described in "Edge Pitch" chapter (page 4-56 of the user manual).

# Laboratory Course n° 4


—

## Compact Vision System

---

### Caps Detection

You have to program the detection of perfume caps on the holder.



Select the appropriate tool to perform this detection.

**Give your conclusions about compact vision systems**