

# Laboratory Course n° 3

## –

## Lens & Lighting

---

### *Objective*

Taking into account the scene you have to image and features to be detected, you have to choose:

- Lens
- Lighting configuration to implement.

### *Equipment*

- PC Computer
- Frame Grabber : National Instruments PCI-1428
- JAI CV M4+ CL Digital Camera
- 12V Power Supply
- Video Cables
- Industrial Lenses
- Extension Rings
- Lighting Devices
- Industrial Parts

### *Software*

National Instruments "Measurement & Automation Explorer" Software

### *Documentation*

- User Manual - National Instruments PCI-1428 Frame Grabber
- User Manual - JAI CV M4+ CL
- Lectures on Machine Vision

# Laboratory Course n° 3

## Lens & Lighting

---


### Lens

In order to carry out this step, consult the following documentation:

- Camera Brochure
- Lectures on Machine Vision

You have to observe the fork in order to perform surface inspection with the following specifications:

- Working Distance : 500 mm



**Choose the right lens.**

Mount the selected lens on the camera and check that the computation is OK:

1. Connect Camera cables.
2. Start National Instruments "Measurement & Automation Explorer" software.
3. Select camera in "Périphériques & Interfaces => IMAQ PCI 1428" menu
4. Start Grabbing images.

**Ask professor to validate once everything is OK.**

**Compute the obtained "Spatial Resolution"**

**Select different settings and study performances w/r to full or partial frame acquisition => Select "Properties" and navigate in tabs.**

**Give your conclusions on the Camera Link Standard**

### Extension Rings

Mount different extension rings and observe the influence on the acquisition.

**Give your conclusions on the use of extension rings**

# Laboratory Course n° 3

–

## Lens & Lighting

---

### Lighting

In order to carry out this step, consult the following documentation:

- Lectures on Machine Vision

#### **Part N°1 – Silhouette Analysis**

Setup your system in order to observe the contours of the fork

#### **Part N°2 – Defect Detection on Shiny Surface**

Setup your system in order to observe holes & scratches on the surface of the object

For each part, select lens and lighting configuration.

Implement and test your choices

**Start grabbing images and ask professor to validate each configuration once everything is OK.**

# Laboratory Course n° 3

## Lens & Lighting

---

### Lab Bonus - Surface Inspection

#### Machine Vision Configuration

Use LEDs lighting sources to perform the following parts:

1. Center of Oil Filter
2. Magnet
3. Coin detection

For each solution estimate the budget with the online catalogue of Edmund Optics.

**Ask professor to validate once your solution is configured.**

Give your conclusions on the lighting techniques.

For each solution estimate the budget with the online catalogue of Edmund Optics:

<http://www.edmundoptics.com> (choose Poland Country for € cotation)

### End of Lab Course

- Disconnect Cables
- Uninstall every lighting devices